605XE EVENT STOPWATCH
OPERATING INSTRUCTIONS

EVENT STOPWATCH

A or C	→	Start
A or C	→	Stop (time out)
A or C	→	Restart (time in)
A or C	→	Stop
B	→	Reset

NO-PROOF-OF-PURCHASE LIMITED WARRANTY
See label on back of unit for details, or check
http://support.ACCUSPLIT.com

SPECIFICATIONS

Operating Temperature

14°F to 138°F (-10°C to 59°C)

Quartz Crystal Accuracy

±0.002% (accuracy may vary with shock, temperature, or aging of crystal).

Batteries

Batteries should last for 3 years. If display becomes dim, open back and replace with Duracell D357, Eveready D357, or Ray-O-Vac RW42.



ACCUSPLIT, Inc. • 6120 Stoneridge Mall Rd., Suite 210 • Pleasanton, CA 94588 USA
800-965-2008 • 925-226-0888 • FAX 925-463-0147 • www.ACCUSPLIT.com • support@ACCUSPLIT.com

Downloaded from www.Manualslib.com manuals search engine